

Water Pressure Reducing Valve

INSTALLATION & MAINTENANCE MODEL 20-REM-RA

INSTALLATION INSTRUCTIONS

- Install valve in line with arrow on valve body pointing in direction of flow.
- Before installing reducing valve, flush out line to remove loose dirt and scale which might damage the piston.
- All valves will be furnished with stock settings to reduce to 500kPa.
- To re-adjust reduced pressure, loosen white plastic cap and use an allen key to adjust seat. Turn clockwise to raise reduced pressure, or counterclockwise to lower reduced pressure.
- May be installed in a horizontal or vertical position.
- Must be installed in an accessible location for inspection and maintenance purposes

NOTICE: Annual inspection and maintenance is required of all plumbing system components. To ensure proper performance and maximum life, this product must be subject to regular inspection, testing and cleaning.

Regulators in series: Where the desired pressure reduction is more than a 4 to 1 ratio (i.e. 2000kPa to 500kPa), multiple regulators in series should be installed.

PERFORMANCE

MODEL 20-REM-RA FEATURES	
Max. Working Water Pressure	2000kPa
Max. Working Temperature	80° Celsius
Reduced Pressure Range	150-550kPa
Factory Preset	500kPa
Maximum Reduction	4 to 1

STANDARDS COMPLIANCE

- Australian Watermark Approved Lic. SAIG-WM-022859
- Certified to Australian Standards AS/NZS 1357.2:2005





CAUTION:

Any time a reducing valve is adjusted, a pressure gauge must be used downstream to verify correct pressure setting.

Valve may be installed in any position.

WARRANTY: ZURN WILKINS Valves are guaranteed against defects of material or workmanship when used for the services recommended. Please refer to the Zurn Australia / Zurn Wilkins Product Warranty Statement for details.